







Note: Always swab self sealing port with sterile alcohol prior to accessing with a sterile syringe

<p>Step 1:</p>  <p>Draw 3mL of Sodium Citrate Anticoagulant into 30mL Syringe</p>	<p>Step 2:</p>  <p>Draw 27mL whole blood from the patient, filling the syringe to 30mL</p>	<p>Step 3:</p>  <p>Load anticoagulated whole blood into the Concentrating Device</p>	<p>Step 4:</p> <p>Counterbalance and process the Concentrating Device at</p> <p>Executive Series Centrifuge 5 minutes 4400 RPM</p> <p>Platinum Series Centrifuge Pre-Programmed Setting: "AbsolutePRP/BMC"</p>
<p>Step 5:</p>  <p>Attach the 30mL syringe and aspirate the plasma until the piston touches the RBC interface (trapping the plasma & platelet buffycoat inside), then stop aspirating</p>		<p>Step 6:</p>  <p>Attach the 12mL syringe and aspirate 3-4mL PRP (Rotate the syringe to re-suspend the platelet buffycoat into the plasma)</p>	<p>Step 7:</p>  <p>Attach the female-female connector to the plasma & PRP syringe. Aspirate plasma from the plasma syringe into the PRP syringe to attain the desired PRP volume.</p>