














**BC120-PURE \*\* PLEASE DISCARD RED VENTED CAP FROM CONCENTRATING DEVICE BEFORE USE \*\***

**Note:** Always swab self sealing port with sterile alcohol prior to accessing with a sterile syringe.

<p><b>Step 1:</b></p>  <p>Using the filtered needle draw up 6mL of Sodium Citrate Anticoagulant into each 60mL Syringe</p>	<p><b>Step 2:</b></p>  <p>Draw 54ml of Bone Marrow Aspirate from the patient in each syringe, filling each syringe to 60 ml. Draw total of 108 ml BMA.</p>	<p><b>Step 3:</b></p>  <p>Filter from syringe to syringe by simultaneously pushing and pulling each syringe. Filter the BMA in the direction indicated on the filter.</p>	<p><b>Step 4:</b></p>  <p>Inject anticoagulated &amp; filtered bone marrow into each <b>Concentrating Device</b>.</p>	<p><b>Step 5:</b></p> <p>Counterbalance at opposite ends and process the <b>Concentrating Device</b>.</p> <p><b>Executive Series Centrifuge Setting:</b> 2.5 minutes 3800 RPM</p> <p><b>Platinum Series Centrifuge Pre-Programmed Setting:</b> "PureBMC® SP Spin 1"</p> 
<p><b>Step 5:</b></p>  <p>Aspirate the BMA plasma into each 60mL syringe. Once the RBC fill the pipe, open the stopcock to the 3mL syringe and aspirate 2mL of BMA red blood cells from each device (total of 4mL of RBC's)</p>	<p><b>Step 6:</b></p>  <p>Inject 2mL BMA RBC FIRST</p> <p>Transfer the BMA RBC from each 3mL syringe first, then transfer BMA plasma from each 60mL syringe into the <b>Concentrating Accessory</b></p>	<p><b>Step 7:</b></p> <p>Counterbalance at opposite ends and process the <b>Concentrating Device</b>.</p> <p><b>Executive Series Centrifuge Setting:</b> 7 minutes 3800 RPM</p> <p><b>Platinum Series Centrifuge Pre-Programmed Setting:</b> "PureBMC® SP Spin 2"</p> 	<p><b>Step 8:</b></p>  <p>Bone marrow cell concentrate buffycoat separates out at the bottom of the <b>Concentrating Accessory</b></p>	
<p><b>Step 9:</b></p>  <p>Aspirate BMA Plasma from the Concentrating Accessory. Leave approximately 14 mL</p>	<p><b>Step 10:</b></p>  <p>Attach the 20 mL syringe and swirl to resuspend the BMA buffycoat into the plasma.</p>	<p><b>Step 11:</b></p>  <p>Tilt to immerse Aspirating Pipe into PureBMC®</p>	<p><b>Step 12:</b></p>  <p>Extract the PureBMC® into the 20 mL syringe.</p>	